

Adhesives

Protect-All 127

Coverage Rate: 70 – 80 sf
Work time: 20 – 30 minutes

Process:

- Completely mix part B into part A, look for consistent color mix
- Spread with 1/8" x 1/8" x 1/16" V-notch trowel
- Can be welded after 12 hours
- Light foot traffic after 12 hours

Protect-All 139

Coverage Rate: 70 – 80 sf
Work time: 10 – 20 minutes

Process:

- Completely mix part B into part A, look for consistent color mix
- Spread with 1/8" x 1/8" x 1/16" V-notch trowel
- Can be welded after 6 hours
- Light foot traffic after 6 hours

NOTES:

Excess adhesive can be cleaned using a moist, damp cloth before adhesive cures

Lay 4x8 sheets of wood to disperse weight if early access is needed

Both products have a 1 year shelf life from manufacturer's date
Ex: D4K0658 D= location 4=year 2014/K=month October

To learn more, contact the Protect-All Technical Department at:



Technical Bulletin
Bulletin 2: OP-002
Updated 6/2016

800.544.9538