



Note 1: Flooring must be routed prior to installation for smooth, flat transition.

Note 2: One bead being co-radial with anchor radius and one being 1/2 in. (13 mm) from the inside of the drain ring.

Note 3: Squeeze E6100 underneath the flap and press with a hand roller to ensure the sealant spreads underneath.

Note 4: Fill anchor holes with E6100 sealant.

REVISED:	N/A	DRAIN RING
PREVIOUS:	04/08/2026	GENERAL DETAIL
SCALE:	NONE	PROTECT-ALL FLOORING