

**Technical Bulletin** Bulletin 7: OP-007 Updated 7/2015

# **Jobsites & Subfloors**

#### **Jobsite Requirements**

- Windows and doors must be installed
- HVAC system must be in operation a minimum of 7 days prior to, during, and after installation
- Protect-All must be acclimated on-site for a minimum of 24 hours in the installation environment

#### Acceptable Substrates & Subfloor Requirements

- Portland based cement
- Cement board
- Marine grade plywood
- Underlayment grade
- Cement based levelers or skim coats
- Substrates must be clean, dry, and structurally sound
- Substrate tests
  - 5lb, 1k sf, 24hr calcium chloride test
  - 85% or less relative humidity
  - o Neutral PH

### **NOTE:** Gypsum based products and Luan are not compatible products

To learn more, contact the Technical Department at:

## 800.544.9538

www.protect-allflooring.com